



SM01 SMART RTV-1




Potrzebne narzędzia





N O   x15	T P   x15	M R   x15
A2 S  x2	A3 T  x2	A1 U  x4
E W   x13	S8 Y  M8x30 x2	S1 Z  4x16 x8 
D2 Z1   x8		


1




2






3





4





5





6




7




8




9




10




11




12




13



14



15



Zawiasy - sposób regulowania

